



Quick Install Guide for Weed Guard on MARLIN or MAKO System

1. Remove motor from mount: Remove the existing 2 screws holding motor to the rudder mount.



2. Pass the red motor connector plug through the opening of the weed guard.



3. Align the weed guard and motor mount screw holes. Install the 2 provided longer hex screws using the 2.5 mm hex key included.



4. Now you are ready to get in the weeds!